

Please Note: It is possible to start the engine with the kill cord not attached. This is a design feature of the unit, to allow the crew to re-start the engine should the helm fall overboard. Please take care when installing the kill cord.